

www.tefal.com  www.calor.fr

1.

www.tefal.com  www.calor.fr



2.

www.tefal.com  www.calor.fr

 **ON**  **ON**

  **MODE** **LED 2sec**

 **OK**

 **ON**  **ON**

  **MODE** **LED 2sec**

 **OK**

 **ON**  **ON**

  **MODE** **LED 2sec**

 **OK**

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

 ON **ON**

 MODE **LED 2sec**

 OK

2.



www.tefal.com

www.calor.fr








3.

www.tefal.com  www.calor.fr

MODE

Normal	Eco	Normal
		
Normal	Normal	Normal
		
Normal	Max	Normal
		

4.

www.tefal.com

www.calor.fr

Eco Normal

MODE

LED 2sec

8 min

OFF

ON

OK

NO

5.

www.tefal.com

www.calor.fr

AUTO OFF

8 min

OFF

ON

OK

6.

www.tefal.com

www.calor.fr

LIGHT

OFF

ON

2s

2s

7.

www.tefal.com

www.calor.fr

ANTI CALC

OFF

ON

2s

2s

3s

2 min

8.

www.tefal.com

www.calor.fr

OFF

1H

2H

9.

www.tefal.com

www.calor.fr

OFF

2H

FR Guide de l'utilisateur
EN User's guide
DE Bedienungsanleitung
NL Gebruiksaanwijzing
ES Guía del usuario
PT Guia del usuario
IT Manuale d'uso
DA Brugsvejledning
NO Bruksanvisning
SV Användarhandbok
FI Käyttöopas
TR Kullanım kılavuzu
EL Οδηγός χρήσης
CS Návod k použití
SK Používateľská príručka

HU Használati útmutató
SL Navodila za uporabnika
RU Руководство пользователя
UK Посібник користувача
HR Upute za uporabu
RO Ghidul utilizatorului
ET Kasutusjuhend
LT Naudotojo vadovas
LV Lietošanas pamācība
BG Ръководство на потребителя
SR Korisničko uputstvo
BS Korisnički priručnik
AR دليل المستخدم
PL Instrukcja obsługi
TH คู่มือสำหรับผู้ใช้
ZH 使用指南



EXPRESS POWER / EXPRESS VISION

FR Pour plus d'informations sur l'utilisation / EN For further usage information / DE Weitere Informationen zur Bedienung / NL Voor meer informatie over het gebruik / ES Para obtener más información sobre su uso / PT Para obter mais informações sobre a utilização / IT Per maggiori informazioni sull'utilizzo / DA Yderligere informationer vedrørende betjening / NO For mer informasjon om bruken / SV Yderligere information om användningen / FI Lisätietoja käyttäjä varten / TR Kullanım hakkında daha fazla bilgi için / EL Για περισσότερες πληροφορίες σχετικά με τη χρήση / PL Więcej informacji na temat korzystania z urządzenia / CS Pro více informací o použití / SK Pre ďalšie informácie o používaní / HU A használatra vonatkozó további információk / SL Več informacij o uporabi / RU Для получения более подробной информации об эксплуатации / UK Для отримання детальної інформації щодо експлуатації / HR Za više informacija o upotrebi / RO Pentru mai multe informații privind utilizarea / ET Täiendava teabe saamiseks kasutamise kohta / LT Daugiau informacijos apie naudojimą / LV Lai iegūtu vairāk informācijas par lietošanu / BG За още информация относно употребата / BS Za više informacija o upotrebi / SR Za više informacija o upotrebi / AR للمزيد من المعلومات عن الإستعمال / FA برای اطلاعات بیشتر درباره نحوه استفاده / TH สำหรับข้อมูลเพิ่มเติมเกี่ยวกับการใช้งาน / ZH 更多关于使用的信息: